

ISTRUZIONI DI MONTAGGIO

INSTALLATION INSTRUCTIONS

A




B




C

Per Art-09653/3-(519/3EU)
For item 09653/3-(519/3EU)




D


Per Art-519/3
For item 519/3




E



F



Art-82519/3 -- Item-82519/3



PRESSIONE MINIMA DI SERVIZIO :.....0,5 bar
PRESSIONE DI SERVIZIO MASSIMA :.....5 bar
PRESSIONE D'USO CONSIGLIATA :.....3 bar
TEMPERATURA ACQUA CALDA MAX :..... 80°C
TEMPERATURA ACQUA CALDA CONSIGLIATA :.....60°C

In caso di pressione d'esercizio superiore a 5 bar è consigliabile installare un riduttore di pressione sulle tubature di alimentazione.

MINIMUM WORKING PRESSURE:.....0,5 bar
MAX OPERATING PRESSURE :.....5 bar
RECOMMENDED OPERATION PRESSURE :.....3 bar
MAX HOT WATER TEMPERATURE :.....80°C
RECOMMENDED HOT WATER TEMPERATURE :.....60°C

In case of operating pressures higher than 5 bar it is recommended to install a pressure reducer on the feeding tubes.

© Copyright of Mario Bongio s.r.l.

Istruzioni montaggio
Per Art.82519/3
E parti esterne per
Art - 09653/3

Installation instruction
For item - 82519/3
And external parts for
Item 09653/3

bongio

Mario Bongio s.r.l.
Via Aldo Moro, 2
28017 San Maurizio d'Opaglio (NO) - Italy
tel: +39 0322 967248 **fax:** +39 0322 950012
www.bongio.com - info@bongio.it